HT-C750W
HT-C755W

# Digital Home Cinema System

## user manual

Imagine the possibilities

Thank you for purchasing this Samsung product.
To receive more complete service,
please register your product at
www.samsung.com/register

SAMSUNG

# Safety Information

## Safety Warnings

TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE THE COVER(OR BACK).
NO USER-SERVICEABLE PARTS ARE INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

| | | |
|---|---|---|
| This symbol indicates “dangerous voltage” inside the product that presents a risk of electric shock or personal injury. | **CAUTION** : TO PREVENT ELECTRIC SHOCK, MATCH WIDE BLADE OF PLUG TO WIDE SLOT, FULLY INSERT. | This symbol indicates important instructions accompanying the product. |

### WARNING

- To reduce the risk of fire or electric shock, do not expose this appliance to rain or moisture.

### CAUTION

- Apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall be placed on the apparatus.
- The Mains plug is used as a disconnect device and shall stay readily operable at any time.
- This apparatus shall always be connected to a AC outlet with a protective grounding connection.
- To disconnect the apparatus from the mains, the plug must be pulled out from the mains socket, therefore the mains plug shall be readily operable.

| | |
|---|---|
| **CLASS 1** | **LASER PRODUCT** |
| **KLASSE 1** | **LASER PRODUKT** |
| **LUOKAN 1** | **LASER LAITE** |
| **KLASS 1** | **LASER APPARAT** |
| **PRODUCTO** | **LÁSER CLASE 1** |

### CLASS 1 LASER PRODUCT

This Compact Disc player is classified as a CLASS 1 LASER product.
Use of controls, adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

### CAUTION

- INVISIBLE LASER RADIATION WHEN OPEN AND INTERLOCKS DEFEATED, AVOID EXPOSURE TO BEAM.

## Precautions

- Ensure that the AC power supply in your house complies with the identification sticker located on the back of your product.
- Install your product horizontally, on a suitable base (furniture), with enough space around it for ventilation (7.5~10cm).
- Do not place the product on amplifiers or other equipment which may become hot.
  Make sure the ventilation slots are not covered.
- Do not stack anything on top of the product.
- Before moving the product, ensure the Disc Insert Hole is empty.
- In order to disconnect the product completely from the power supply, remove the AC plug from the wall outlet, especially when left unused for a long period of time.
- During thunderstorms, disconnect the AC plug from the wall outlet. Voltage peaks due to lightning could damage the product.
- Do not expose the product to direct sunlight or other heat sources. This could lead to overheating and malfunction of the product.
- Protect the product from moisture, and excess heat or equipment creating strong magnetic or electric fields (i.e. speakers.).
- Disconnect the power cable from the AC supply if the product malfunctions.
- Your product is not intended for industrial use. Use of this product is for personal use only.
- Condensation may occur if your product or disc has been stored in cold temperatures. If transporting the product during the winter, wait approximately 2 hours until the product has reached room temperature before using.
- The batteries used with this product contain chemicals that are harmful to the environment.
  Do not dispose of batteries in the general household trash.

## Accessories

Check for the supplied accessories below.

| Video Cable | FM Antenna | iPod Dock (Option) | ASC microphone |
|---|---|---|---|




| HDMI Cable | User's Manual | Remote Control/Batteries (AAA size) | Toroidal Ferrite Core |
|---|---|---|---|

# Safety Information

## Cautions on Handling and Storing Discs

Small scratches on the disc may reduce sound and picture quality or cause skipping.

Be especially careful not to scratch discs when handling them.

### Holding discs

- Do not touch the playback side of the disc.
- Hold the disc by the edges so that fingerprints will not get on the surface.
- Do not stick paper or tape on the disc.

### Disc Storage

- Do not keep in direct sunlight
- Keep in a cool ventilated area
- Keep in a clean Protection jacket.
  Store vertically.

**NOTE**

- Do not allow the discs to become contaminated with dirt.
- Do not load cracked or scratched discs.

### Handling and Storing Discs

If you get fingerprints or dirt on the disc, clean it with a mild detergent diluted in water and wipe with a soft cloth.

- When cleaning, wipe gently from the inside to the outside of the disc

**NOTE**

- Condensation may form if warm air comes into contact with cold parts inside the product. When condensation forms inside the product, it may not operate correctly. If this occurs, remove the disc and let the product stand for 1 or 2 hours with the power on.

## Licence

- ABOUT DIVX VIDEO: DivX® is a digital video format created by DivX,Inc. This is an official DivX Certified device that plays DivX video. Visit www.divx.com for more information and software tools to convert your files into DivX video. ABOUT DIVX VIDEO-ON-DEMAND: This DivX Certified® device must be registered in order to play DivX Video-on-Demand (VOD) content. To generate the registration code, locate the DivX VOD section in the device setup menu. Go to vod.divx.com with this code to complete the registration process and learn more about DivX VOD.
- DivX Certified® to play DivX ® video
- **iPod is a trademark of Apple Inc., registered in the U.S. and other countries.**
  **iPhone is a trademark of Apple Inc.**
- Dolby and the double-D symbol are registered trademarks of Dolby Laboratories.
- "Pat. 7,295,673; 7,460,688; 7,519,274"

## Copyright

© 2010 Samsung Electronics Co., Ltd. All rights reserved.

## Copy Protection

- Many DVD discs are encoded with copy protection. Because of this, you should only connect your product directly to your TV, not to a VCR. Connecting to a VCR results in a distorted picture from copy-protected DVD discs.
- This item incorporates copy protection technology that is protected by U.S. patents and other intellectual property rights of Rovi Corporation. Reverse engineering and disassembly are prohibited.

# Contents


**SAFETY INFORMATION** 2

2 Safety Warnings
3 Precautions
3 Accessories
4 Cautions on Handling and Storing Discs
4 Licence
4 Copyright
4 Copy Protection

**GETTING STARTED** 7

7 Icons that will be used in manual
7 Disc Types and Characteristics
11 Description
11 Front Panel
12 Rear Panel
13 Remote control

**CONNECTIONS** 15

15 Connecting the Speakers
20 Attaching the Toroidal Ferrite Core to the Power Cord of the Main Unit
21 Connecting the Video Out to your TV
23 Connecting the FM Antenna
23 Connecting Audio from External Components

**SETUP** 25

25 Before Starting (Initial Setting)
25 Setting the Setup menu
26 Display
26 TV Aspect
26 BD Wise
26 Resolution
26 HDMI Format
27 Audio
27 Speaker Setting
28 ASC (Auto Sound Calibration) Setting
29 DRC (Dynamic Range Compression)
29 AV-SYNC
29 HDMI AUDIO
29 EQ Optimizer
30 System
30 Initial Setting
30 DivX(R) Registration
30 Language
30 Security
30 Parental Rating
30 Change Password
30 Support
30 Product Information

# Contents


**BASIC FUNCTIONS** 31

31 Disc Playback
31 Audio CD(CD-DA)/MP3/WMA Playback
32 JPEG File Playback
32 Using the Playback Function
36 Sound Mode
38 Listening to Radio
38 Connecting Microphone

**ADVANCED FUNCTIONS** 39

39 USB Function
39 Using an iPod (Option)
41 CD Ripping

**OTHER INFORMATION** 42

42 Troubleshooting
43 Country code list
44 Specifications


- Figures and illustrations in this User Manual are provided for reference only and may differ from actual product appearance.

# Getting Started

## Icons that will be used in manual

Make sure to check the following terms before reading the user manual.

| Icon | Term | Definition |
|---|---|---|
| | DVD | This involves a function available with DVD-Video or DVD±R/±RW discs that have been recorded and finalised in Video Mode. |
| | CD | This involves a function available with a data CD (CD DA, CD-R/-RW). |
| | MP3 | This involves a function available with CD-R/-RW discs. |
| | JPEG | This involves a function available with CD-R/-RW discs. |
| | DivX | This involves a function available with MPEG4 discs. (DVD±R/±RW, CD-R/-RW) |
| ! | CAUTION | This involves a case where a function does not operate or settings may be cancelled. |
| | NOTE | This involves tips or instructions on the page that help each function operate. |
| | Shortcut Key | This function provides direct and easy access pressing the button on the remote control. |

## Disc Types and Characteristics

### Region Code

The product and the discs are coded by region. These regional codes must match in order for the disc to play. If the codes do not match, the disc will not play.

| Disc Type | Region Code | Area |
|---|---|---|
| DVD-VIDEO | | The U.S., U.S. territories and Canada |
| | | Europe, Japan, the Middle East, Egypt, South Africa, Greenland |
| | | Taiwan, Korea, the Philippines, Indonesia, Hong Kong |
| | | Mexico, South America, Central America, Australia, New Zealand, Pacific Islands, Caribbean |
| | | Russia, Eastern Europe, India, most of Africa, North Korea, Mongolia |
| | | China |

## Disc types that can be played

| Disc Types & Mark (Logo) | Recorded Signals | Disc Size | Max. Playing Time |
|---|---|---|---|
| DVD-VIDEO | VIDEO | 12 cm | Approx. 240 min. (single-sided) |
| | | | Approx. 480 min. (double-sided) |
| | | 8 cm | Approx. 80 min. (single-sided) |
| | | | Approx. 160 min. (double-sided) |
| AUDIO-CD | AUDIO | 12 cm | 74 min. |
| | | 8 cm | 20 min. |
| DivX | AUDIO + VIDEO | 12 cm | – |
| | | 8 cm | – |

## Do not use the following types of disc!

- LD, CD-G, CD-I, CD-ROM, DVD-ROM and DVD-RAM discs cannot be played on this product. If such discs are played, a <WRONG DISC FORMAT> message appears on the TV screen.
- DVD discs purchased abroad may not play on this product.
  If such discs are played, a <Wrong Region. Please check Disc.> message appears on the TV screen.

## Disc Types And Disc Format

This product does not support Secure (DRM) Media files.

### CD-R Discs

- Some CD-R discs may not be playable depending on the disc recording device (CD-Recorder or PC) and the condition of the disc.
- Use a 650MB/74 minute CD-R disc.
  Do not use CD-R discs over 700MB/80 minutes as they may not be played back.
- Some CD-RW (Rewritable) media, may not be playable.
- Only CD-Rs that are properly "closed" can be fully played. If the session is closed but the disc is left open, you may not be able to fully play the disc.

### CD-R MP3 Discs

- Only CD-R discs with MP3 files in ISO 9660 or Joliet format can be played.
- MP3 file names should contain no blank spaces or special characters (. / = +).
- Use discs recorded with a compression/ decompression data rate greater than 128Kbps.
- Only files with the ".mp3" and ".MP3" extensions can be played.
- Only a consecutively written multisession disc can be played. If there is a blank segment in the Multisession disc, the disc can be played only up to the blank segment.
- If the disc is not closed, it will take longer to begin playback and not all of the recorded files may be played.
- For files encoded in Variable Bit Rate (VBR) format, i.e. files encoded in both low bit rate and high bit rate (e.g., 32Kbps ~ 320Kbps), the sound may skip during playback.
- A maximum of 500 tracks can be played per CD.
- A maximum of 300 folders can be played per CD.

### CD-R JPEG Discs

- Only files with the "jpg" extensions can be played.
- If the disc is not closed, it will take longer to start playing and not all of the recorded files may be played.
- Only CD-R discs with JPEG files in ISO 9660 or Joliet format can be played.
- JPEG file names should be 8 characters or less in length and contain no blank spaces or special characters (. / = +).
- Only a consecutively written multisession disc can be played. If there is a blank segment in the multisession disc, the disc can be played only up to the blank segment.
- A maximum of 999 images can be stored on a folder.
- When playing a Kodak/Fuji Picture CD, only the JPEG files in the picture folder can be played.
- Picture discs other than Kodak/Fuji Picture CDs may take longer to start playing or may not play at all.

## DVD±R/±RW, CD-R/RW Discs

- Software updates for incompatible formats are not supported.
  (Example : QPEL, GMC, resolution higher than 800 x 600 pixels, etc.)
- If a DVD-R/-RW disc has not been recorded properly in DVD Video format, it will not be playable.

## DivX (Digital internet video express)

DivX is a video file format developed by Microsoft and is based on MPEG4 compression technology to provide audio and video data over the Internet in real-time.

MPEG4 is used for video encoding and MP3 for audio encoding so that the users can watch a movie at near DVD-quality video and audio.

### Supported Formats (DivX)

This product only supports the following media formats. If both video and audio formats are not supported, the user may experience problems such as broken images or no sound.

Supported Video Formats

| Format | Supported Versions |
|---|---|
| AVI | DivX3.11~DivX5.1, XviD |
| WMV | V1/V2/V3/V7 |

Supported Audio Formats

| Format | Bit Rate | Sampling Frequency |
|---|---|---|
| MP3 | 80~320kbps | 44.1khz |
| WMA | 56~128kbps | |
| AC3 | 128~384kbps | 44.1/48khz |
| DTS | 1.5Mbps | 44.1khz |

- DivX files, including audio and video files, created in the DTS format can only support up to 6Mbps.
- Aspect Ratio : Although the default DivX resolution is 640x480 pixels, this product supports up to 720x480 pixels. TV screen resolutions higher than 800 will not be supported.
- When you play a disc whose sampling frequency is higher than 48khz or 320kbps, you may experience shaking on the screen during playback.
- Sections with a high frame rate might not be played while playing a DivX file.
- Since this product only provides encoding formats authorized by DivX Networks, Inc., a DivX file created by the user might not play.

## Notes on USB connection

Supported devices: USB storage media, MP3 player, digital camera, USB card reader

1. If a folder or file name is longer than 10 characters, it may not properly display or operate.
2. A subtitle file bigger than 148KB may not be properly displayed.
3. A certain USB/digital camera device, USB card reader may not be compatible with the product.
4. FAT16 and FAT32 file systems are supported.

   ✳ NTFS file system is not supported.
5. Photo (JPEG), music (MP3, WMA) and video file should have their names in Korean or English. Otherwise, the file may not played.
6. Connect directly to the product's USB port. Connecting through another cable may raise problems with USB compatibility.
7. Inserting more than one memory device to a multi-card reader may not operate properly.
8. PTP protocol for digital camera is not supported.
9. Do not disconnect USB device during a "Reading" process.
10. Bigger the image resolution, the longer the delay to displaying.
11. DRM applied MP3/WMA or video files downloaded from a commercial site are not played back.
12. External HDD device is not supported.
13. Supported file formats

### Supported file Formats

| Format | Still Picture | Music | | Movie | |
|---|---|---|---|---|---|
| File name | JPG | MP3 | WMA | WMV | DivX |
| File extension | JPG .JPEG | .MP3 | .WMA | .WMV | .AVI |
| Bit rate | – | 80~320 kbps | 56~128 kbps | 4Mbps | 4Mbps |
| Version | – | – | V8 | V1,V2, V3,V7 | DivX3.11~ DivX5.1, XviD |
| Pixel | 640x480 | – | – | 720x480 | |
| Sampling Frequency | – | 44.1kHz | 44.1kHz | 44.1KHz~ 48KHz | |

## Description

### Front Panel




| | | |
|---|---|---|
| 1 | EJECT BUTTON ( ⏏ ) | Ejects a disc. |
| 2 | FUNCTION BUTTON ( FUNC. ) | The mode switches as follows :<br>DVD/CD ➞ D.IN ➞ AUX 1 ➞ AUX 2 ➞ USB ➞ IPOD (Option) ➞ FM. |
| 3 | TUNING DOWN & SKIP BUTTON ( ⏮ ) | Goes back to the previous title/chapter/track.<br>Tunes down the FM frequency band. |
| 4 | STOP BUTTON ( ⏹ ) | Stops disc playback. |
| 5 | PLAY/PAUSE BUTTON ( ⏯ ) | Plays a disc or pauses playback. |
| 6 | TUNING UP & SKIP BUTTON ( ⏭ ) | Goes to the next title/chapter/track.<br>Tunes up the FM frequency band. |
| 7 | VOLUME CONTROL BUTTON ( −, + ) | Volume adjustment. |
| 8 | POWER BUTTON ( ⏻ ) | Turns the product on and off. |
| 9 | MIC 1,2 JACK | Connect up to two microphones. |
| 10 | AUX IN 1/ASC IN CONNECTOR | Connect external components such as an MP3 player.<br>Connect to use the ASC (Auto Sound Calibration) function. |
| 11 | USB PORT | Connect here and play files from external USB storage devices such as MP3 players, USB flash memory, etc. |
| 12 | iPod JACK (Option) | Connect the iPod dock connector here.<br>(* Some models do not have this jack.) |
| 13 | DISC SLOT | Insert disc here. |
| 14 | REMOTE CONTROL SENSOR | Detects signals from the remote control. |
| 15 | DISPLAY | Displays the playing status, time, etc. |

# Getting Started

## Rear Panel




| | | |
|---|---|---|
| 1 | HDMI OUT JACK | Using an HDMI cable, connect this HDMI output jack to the HDMI input jack on your TV for the best quality picture. |
| 2 | COMPONENT VIDEO OUTPUT JACKS | Connect a TV with Component video inputs to these jacks. |
| 3 | VIDEO OUT JACK | Connect your TV's Video Input jack (VIDEO IN) to the VIDEO OUT jack. |
| 4 | AUX IN 2 JACKS | Connect to the 2CH Analogue output of an external device (such as a VCR). |
| 5 | EXTERNAL DIGITAL OPTICAL IN JACK (OPTICAL) | Use this to connect external equipment capable of digital output. |
| 6 | SPEAKER OUTPUT CONNECTORS | Connect the front, centre, subwoofer speakers. |
| 7 | TX CARD CONNECTION (WIRELESS) | The TX card enables communication between the product and the wireless receiver module. |
| 8 | FM ANTENNA JACK | Connect the FM antenna. |
| 9 | COOLING FAN | The cooling fan supplies cool air to the product to prevent overheating and always revolves when the power is on. |

## Tour of the Remote Control




Turn the product on and off.

If you want to change to Home Cinema or TV mode on the remote control, check this button's LED colour.
Home Cinema: Orange
TV : Green

Press the number button to operate options.

Select the desired Dolby Pro Logic II audio mode.

Press to skip backwards or forwards.

Press to stop/play a disc.

Cut off the sound temporarily.

Adjust the volume.

Press this to move to the home menu.

Press to check the disc menu.

Used to change the audio/subtitle language, angle etc.

Select on-screen menu items and change menu value.

Return to the previous menu.

Allow access to common functions of the product such as the Photo List.
or
GREEN(B) : Press to preset radio stations.

Adjust the brightness of Display.

Regulate and stabilize the volume level against a drastic volume change.

This is mode selection button.
or
Press to select TV's video mode.

To eject a disc.

SLEEP :Set the time to shut off the product itself.
ECHO :Adjust the echo level of the microphone.

Select the desired DSP/EQ audio mode.

Press to search backwards or forwards.

Press to pause a disc.

TUNING/CH:Search for active radio stations and change channels.
MIC VOL :Adjust the MIC volume.

Allows you to repeat a title, chapter, track or disc.

Use this to enter the Title menu.

Display current disc(file) status.

Exit the menu.

Allow access to common functions of the product such as the Photo List.
or
YELLOW(C) : Select MONO or STEREO for radio broadcasting.
BLUE(D) : Converts audio sound of the CD into a MP3 file format.

Select the desired P.BASS or MP3 ENHANCEMENT mode.

## Installing batteries in the Remote Control

* Battery size: AAA



**NOTE**

- Place batteries in the remote control so they match the polarity : (+) to (+) and (–) to (–).
- Always replace both batteries at the same time.
- Do not expose the batteries to heat or flame.
- The remote control can be used up to approximately 7 meters in a straight line.

## Setting the Remote Control

You can control certain functions of your TV with this remote control.

**When operating a TV with the remote control**

1. Press the **DVD RECEIVER/TV** button to set the remote control to TV mode.
2. Press the **POWER** button to turn on the TV.
3. While holding down the **POWER** button, enter the code corresponding to your brand of TV.
   - If there is more than one code listed for your TV in the table, enter one at a time to determine which code works.
   - **Example : For a Samsung TV**
     While holding down the **POWER** button, use the number buttons to enter 00, 15, 16, 17 and 40.
4. If the TV turns off, the setting is complete.
   - You can use the TV POWER, VOLUME, CHANNEL, and Numeric buttons (0~9).

**NOTE**

- The remote control may not work on some brands of TV's. Also, some operations may not be possible depending on your brand of TV.
- If you do not set the remote control with the code for your brand of TV, the remote control will work on a Samsung TV by default.

## TV Brand Code List

| Brand | Code | Brand | Code |
|---|---|---|---|
| Admiral (M.Wards) | 56, 57, 58 | MTC | 18 |
| A Mark | 01, 15 | NEC | 18, 19, 20, 40, 59, 60 |
| Anam | 01, 02, 03, 04, 05, 06, 07, 08, 09, 10, 11, 12, 13, 14 | Nikei | 03 |
| AOC | 01, 18, 40, 48 | Onking | 03 |
| Bell & Howell (M.Wards) | 57, 58, 81 | Onwa | 03 |
| Brocsonic | 59, 60 | Panasonic | 06, 07, 08, 09, 54, 66, 67, 73, 74 |
| Candle | 18 | Penney | 18 |
| Cetronic | 03 | Philco | 03, 15, 17, 18, 48, 54, 59, 62, 69, 90 |
| Citizen | 03, 18, 25 | Philips | 15, 17, 18, 40, 48, 54, 62, 72 |
| Cinema | 97 | Pioneer | 63, 66, 80, 91 |
| Classic | 03 | Portland | 15, 18, 59 |
| Concerto | 18 | Proton | 40 |
| Contec | 46 | Quasar | 06, 66, 67 |
| Coronado | 15 | Radio Shack | 17, 48, 56, 60, 61, 75 |
| Craig | 03, 05, 61, 82, 83, 84 | RCA/ Proscan | 18, 59, 67, 76, 77, 78, 92, 93, 94 |
| Croslex | 62 | Realistic | 03, 19 |
| Crown | 03 | Sampo | 40 |
| Curtis Mates | 59, 61, 63 | Samsung | 00, 15, 16, 17, 40, 43, 46, 47, 48, 49, |
| CXC | 03 | Sanyo | 19, 61, 65 |
| Daewoo | 02, 03, 04, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 32, 34, 35, 36, 48, 59, 90 | Scott | 03, 40, 60, 61 |
| Daytron | 40 | Sears | 15, 18, 19 |
| Dynasty | 03 | Sharp | 15, 57, 64 |
| Emerson | 03, 15, 40, 46, 59, 61, 64, 82, 83, 84, 85 | Signature 2000 (M.Wards) | 57, 58 |
| Fisher | 19, 65 | Sony | 50, 51, 52, 53, 55 |
| Funai | 03 | Soundesign | 03, 40 |
| Futuretech | 03 | Spectricon | 01 |
| General Electric (GE) | 06, 40, 56, 59, 66, 67, 68 | SSS | 18 |
| Hall Mark | 40 | Sylvania | 18, 40, 48, 54, 59, 60, 62 |
| Hitachi | 15, 18, 50, 59, 69 | Symphonic | 61, 95, 96 |
| Inkel | 45 | Tatung | 06 |
| JC Penny | 56, 59, 67, 86 | Techwood | 18 |
| JVC | 70 | Teknika | 03, 15, 18, 25 |
| KTV | 59, 61, 87, 88 | TMK | 18, 40 |
| KEC | 03, 15, 40 | Toshiba | 19, 57, 63, 71 |
| KMC | 15 | Vidtech | 18 |
| LG (Goldstar) | 01, 15, 16, 17, 37, 38, 39, 40, 41, 42, 43, 44 | Videch | 59, 60, 69 |
| Luxman | 18 | Wards | 15, 17, 18, 40, 48, 54, 60, 64 |
| LXI (Sears) | 19, 54, 56, 59, 60, 62, 63, 65, 71 | Yamaha | 18 |
| Magnavox | 15, 17, 18, 48, 54, 59, 60, 62, 72, 89 | York | 40 |
| Marantz | 40, 54 | Yupiteru | 03 |
| Matsui | 54 | Zenith | 58, 79 |
| MGA | 18, 40 | Zonda | 01 |
| Mitsubishi/ MGA | 18, 40, 59, 60, 75 | Dongyang | 03, 54 |

# Connections

This section involves various methods of connecting the product to other external components.
Before moving or installing the product, be sure to turn off the power and disconnect the power cord.

## Connecting the Speakers




### Position of the product

Place it on a stand or cabinet shelf, or under the TV stand.

### Selecting the Listening Position

The listening position should be located about 2.5 to 3 times the distance of the TV's screen size away from the TV.
Example : For 32" TV's 2~2.4m
For 55" TV's 3.5~4m

| | |
|---|---|
| Front Speakers L R | Place these speakers in front of your listening position, facing inwards (about 45°) toward you. Place the speakers so that their tweeters will be at the same height as your ear. Align the front face of the front speakers with the front face of the centre speaker or place them slightly in front of the centre speakers. |
| Centre Speaker C | It is best to install it at the same height as the front speakers. You can also install it directly over or under the TV. |
| Rear Speakers SL SR | Place these speakers to the side of your listening position. If there isn't enough room, place these speakers so they face each other. Place them about 60 to 90cm above your ear, facing slightly downward.<br>* Unlike the front and centre speakers, the rear speakers are used to handle mainly sound effects and sound will not come from them all the time. |
| Subwoofer SW | The position of the subwoofer is not so critical. Place it anywhere you like. |

**! CAUTION**

- Do not let children play with or near the speakers. They could get hurt if the speaker falls.
- When connecting the speaker wires to the speakers, make sure that the polarity (+/–) is correct.
- Keep the subwoofer out of the reach of children so as to prevent them from inserting their hands or alien substances into the duct (hole) of the subwoofer.
- Do not hang the subwoofer on the wall through the duct (hole).

**✎ NOTE**

- If you place a speaker near your TV set, screen colour may be distorted because of the magnetic field generated by the speaker. If this occurs, place the speaker away from your TV set.

# Connections

## Connecting the Speakers

### Speaker Components

**HT-C750W**




### Speaker Components

**HT-C755W**




### Assembled Speakers




**Wireless Receiver Module : SWA-5000**




**NOTE**

- This product should be connected with the SWA-5000 only.

## Removing/Installing the speaker on the stand

*** HT-C750W**

* Front Speakers only

### How to remove the speaker

If you attach the speaker on the wall, remove the stand before using it.

1. Pull out the stand in the arrow direction as shown.
   - Be careful not to put excessive force when removing it. Otherwise, it can be damaged.
2. This is the appearance after the stand is removed.







### How to install the speaker

1. Connect the stand in the arrow direction so that it fits the corresponding holes (x4) on the speaker.
2. Fully insert the stand in the arrow direction as shown.
3. This is the appearance after the speaker unit is installed.









**Connecting the Speakers**

## Installing the Speakers on the Tallboy Stand

*** HT-C755W**

* Front/Rear Speakers only

1. Connect the Stand Pole to the Stand Bracket.
2. Insert and tighten three large screws (5*15, For connecting Stand Pole & Stand Bracket) into the three holes on the Stand Bracket as shown in the illustration.
3. Straighten the speaker wire and route it through the Stand Pole.
4. Connect the Stand Pole to the Stand Neck and Stand Base.
   - Make sure all holes are properly connected, if not, the stand will fall down.
5. Insert and tighten three large screws (5*15, For connecting Stand Pole & Stand Base) into the three holes on the bottom side of the stand-base as shown in the illustration.

   ! **CAUTION :** When you use a torque screwdriver, be careful not to put excessive force. Otherwise, it runs idle or can be damaged. (torque screwdriver- below 15 kg.f.cm
6. Connect the speaker wire to the speaker jack.
7. Fully insert the Stand Bracket into the speaker's clasp to stand speaker.
8. Insert and tighten two small screws (4*20, For connecting Stand Bracket & Speaker) into the two holes to connect them.
9. This is the appearance after the speaker is installed. Follow this steps to install other speaker.



























## Connecting The Speakers

1. Press down the terminal tab on the back of the speaker.
2. Insert the black wire into the black terminal (–) and the red wire into the red terminal (+), and then release the tab.
3. Connect the connecting plugs to the back of the product by matching the colours of the speaker plugs to the speaker jacks.
4. With the product turned off, insert the TX card into the TX Card Connection (**WIRELESS**) on the back of the product.
   - Hold the TX card so that the label "WIRELESS" faces upward and insert the card into the port.
   - The TX card enables communication between the product and the wireless receiver module.
5. Connect the left and right rear speakers to the wireless Receiver module.
6. Plug the power cord of the wireless Receiver module in the wall outlet .







### In case of HT-C750W




Refer to page 16 for the speakers of HT-755W.

✎ NOTE

- Place the wireless receiver module at the rear of the listening position. If the wireless receiver module is too close to the product, some sound interruption may be heard due to interference.
- If you use a device such as a microwave oven, wireless LAN Card, Bluetooth equipment, or any other device that uses the same frequency (2.4/5.8GHz) near the product, some sound interruption may be heard due to interference.
- The transmission distance from the product to the wireless receiver module is about 10m, but may vary depending on your operating environment. If a steel-concrete wall or metallic wall is between the product and the wireless receiver module, the system may not operate at all, because the radio wave cannot penetrate metal.
- If the product doesn't make wireless connection, the product needs ID Setting between the product and wireless receiver module. With the product turned off, press remote control's number buttons "0"→"1"→"3"→"5" and the message "W INIT" will appear on the display.
- With the wireless receiver module turned on, press "ID SET" button on the back of the wireless receiver module for 5 seconds.

! CAUTION

- Do not insert any other card except the provided TX card.
  If a different TX card is used, the product may be damaged or the card may not be removed easily.
- Do not insert the TX card upside down or in the reverse direction.
- Insert the TX card when the product is turned off. Inserting the card when it is turned on may cause a problem.
- If the TX Card is inserted and wireless receiver module setting is complete, sound is not output from the rear Speaker connectors on the product.
- The wireless receiver antenna is built into the wireless receiver module. Keep it away from water and moisture.
- For optimal listening performance, make sure that the area around the wireless receiver module location is clear of any obstructions.
- **If no sound is heard from the wireless receiver module, switch the mode to DVD 5.1 channel or Dolby ProLogic II .**
- In 2-CH mode, no sound will be heard from the wireless receiver module.

## Attaching the Toroidal Ferrite Core to the Power Cord of the Main Unit

If you attach a Toroidal ferrite core to the power cord of the man unit, it will help to prevent RF interference from radio signals.

1. Pull the fixing tab of the Toroidal ferrite core to open it.
2. Make a loop twice in the main unit power cord.
3. Attach the Toroidal ferrite core to the main unit power cord as the figure shows and press it until it clicks.



## Connecting the Video Out to your TV

Choose one of the three methods for connecting to a TV.




## METHOD 1 : HDMI

Connect an HDMI cable from the **HDMI OUT** jack on the back of the product to the HDMI IN jack on your TV.

## METHOD 2 : Component Video

If your television is equipped with Component Video inputs, connect a Component video cable(not supplied) from the **COMPONENT OUT** (Pr, Pb and Y) jacks on the back of the product to the Component Video Input jacks on your TV.

## METHOD 3 : Composite Video

Connect the supplied Video cable from the **VIDEO OUT** jack on the back of the product to the VIDEO IN jack on your TV.

✎ NOTE

- Resolutions available for the HDMI output are 480p(576p), 720p,1080i/1080p. See page 26 for the resolution setting.
- This product operates in Interlace scan mode 480i(576i) for component/composite output.
- After making the video connection, set the Video input source on your TV to match the corresponding Video output mode on your product.
  See your TV owner's manual for more information on how to select the TV's Video Input source.
- Turn this product on first before you set the video input source on your TV. See your TV owner's manual for more information on how to select the TV's Video Input source.

! CAUTION

- Do not connect the unit through a VCR. Video signals fed through VCRs may be affected by copyright protection systems and the picture will be distorted on the television.

## HDMI FUNCTION

### HDMI Auto Detection Function

The product's video output will automatically change to HDMI mode when connecting an HDMI cable while power is on.

- HDMI (High Definition Multimedia Interface)
- HDMI is an interface that enables the digital transmission of video and audio data with just a single connector. Using HDMI, the product transmits a digital video and audio signal and displays a vivid picture on a TV having an HDMI input jack.
- HDMI connection description
  - HDMI outputs only a pure digital signal to the TV.
  - If your TV does not support HDCP (High-bandwidth Digital Content Protection), random noise appears on the screen.
- What is the HDCP?
- HDCP (High-band width Digital Content Protection) is a system for protecting DVD content outputted via HDMI from being copied. It provides a secure digital link between a video source (PC, DVD. etc) and a display device (TV, projector. etc). Content is encrypted at the source device to prevent unauthorized copies from being made.

✎ NOTE

- When a HDMI cable is connected, composite(Video) and component video signals are not output.

### Using Anynet+(HDMI-CEC)

Anynet+ is a function that enables you to control other Samsung Devices with your Samsung TV's remote control. Anynet + can be used by connecting this product to a SAMSUNG TV using a HDMI Cable. This is only available with SAMSUNG TV's that support Anynet+.

1. Connect the the product to a Samsung TV with an HDMI cable. (See page 21)
2. Set the Anynet+ function on your TV. (See the TV instruction manual for more information.)

✎ NOTE

- The Anynet+ function supports some buttons of the remote control.
- This function is not available if an HDMI cable does not support CEC.
- Depending on your TV, certain HDMI output resolutions may not work.
  Please refer to the user's manual of your TV.
- Please check the Anynet+ logo (If your TV has an Anynet+ logo, then it supports Anynet+ function.)

## Connecting the FM Antenna




1. Connect the FM antenna supplied to the FM Antenna jack.
2. Slowly move the antenna wire around until you find a location where reception is good, then fasten it to a wall or other rigid surface.

**NOTE**

- This product does not receive AM broadcasts.

## Connecting Audio from External Components




## AUX1 : Connecting an External Component/MP3 player

Components such as an MP3 Player.

1. Connect **AUX IN1 / ASC IN** (Audio) on the side of the product to the Audio Out of the external component/ MP3 player.

1. Press the **FUNCTION** button to select **AUX1** input.
   - The mode switches as follows :
     **DVD/CD → D.IN → AUX 1 → AUX 2 → USB → IPOD (Option) → FM**.

**NOTE**

- To optimize the system operation after switching to AUX mode, the signal sound will be output in few seconds.

# Connections

## Connecting Audio from External Components




## AUX2 : Connecting an External Analogue Component

Analogue signal components such as a VCR.

1. Connect **AUX IN 2** (Audio) on the back of the product to the Audio Out of the external Analogue component.
   - Be sure to match the colors of the connecting jacks.
2. Press the **FUNCTION** button to select **AUX 2** input.
   - The mode switches as follows :
     **DVD/CD → D.IN → AUX 1 → AUX 2 → USB → IPOD (Option) → FM**.

**NOTE**

- You can connect the Video Output jack of your VCR to the TV, and connect the Audio Output jacks of the VCR to this product.
- To optimize the system operation after switching to AUX mode, the signal sound will be output in few seconds.

## OPTICAL : Connecting an External Digital Component

Digital signal components such as a Cable Box/Satellite receiver (Set-Top Box).

1. Connect the **DIGITAL AUDIO IN** (**OPTICAL**) on the back of the product to the Digital Output of the external digital component.
2. Press the **FUNCTION** button to select **D.IN**
   - The mode switches as follows :
     **DVD/CD → D.IN → AUX 1 → AUX 2 → USB → IPOD (Option) → FM**.

## Before Starting (Initial Setting)

1. Press the **POWER** button when it is plugged in TV for the first time.
   Initial Setting screen will be displayed.

2. Press the ▲▼ buttons to select the desired language, then press the **ENTER** button.
3. Press the **ENTER** button to select Start button.
4. Press the ▲▼ buttons to select desired TV Aspect, then press the **ENTER** button.
5. Plug the ASC microphone into the ASC IN jack on the product.
   - Auto Sound Calibration screen will be displayed.
6. Press the **ENTER** button to select Start button.

### NOTE

- If the HDMI cable is connected to the product, TV aspect does not appear.
- If you move to the previous screen, press the **RETURN** button.
- Once you select a menu language, you can change it by pressing the **STOP** (■) button on the remote control for more than 5 seconds with no disc.
- When the Initial Setting screen does not appear, refer to Initial Setting. (see page 30)

## Selecting the Video Format

Each country has a different video format standard. You can select the video format either NTSC or PAL. Press and hold the Number 7 button on the remote control for over 5 seconds while the product is turned off.

- "NTSC" or "PAL" will appear on the display. At this time, press the Number 7 button to select either "NTSC" or "PAL".
- The video format of the disc must be the same as he video format of your TV.

## Setting the Setup menu

The access step may differ depending on the selected menu. The GUI (Graphical User Interface) in this manual may differ, depending on the firmware version.




| | |
|---|---|
| 1 | **MENU** BUTTON : Display the home menu. |
| 2 | **RETURN** BUTTON : Return to the previous setup menu. |
| 3 | **ENTER / DIRECTION** BUTTON<br>Move the cursor and select an item.<br>Select the currently selected item.<br>Confirm the setting. |
| 4 | **EXIT** BUTTON : Exit the setup menu. |




1. Press the **POWER** button.
2. Press the ◄► buttons to select **Settings**, then press the **ENTER** button.
3. Press the ▲▼ buttons to select the desired menu, then press the **ENTER** button.
4. Press the ▲▼ buttons to select the desired sub-menu, then press the **ENTER** button.
5. Press the ▲▼ buttons to select the desired item, then press the **ENTER** button.
6. Press the **EXIT** button to exit the setup menu.

## Display

You can configure various display options such as the TV Aspect, Resolution, etc.

### TV Aspect

Depending on the type of television you have, you may want to adjust the screen setting.

| • 4:3 Pan-Scan | |
|---|---|
| | Select when you want to see the 16:9 video supplied by the DVD without the black bars on top and bottom, even though you have a TV with a 4:3 ratio screen(extreme left and right portion of the movie picture will be cut off). |
| • 4:3 Letter Box | |
| | Select when you want to see the total 16:9 ratio screen DVD supplies, even though you have a TV with a 4:3 ratio screen. Black bars will appear at the top and bottom of the screen. |
| • 16:9 Wide | |
| | You can view the full 16:9 picture on your widescreen TV. |

✎ NOTE

- When using HDMI, the screen is automatically converted to the 16:9 Wide mode and TV Aspect is deactivated.
- If a DVD is in the 4:3 ratio, you cannot view it in the wide screen.
- Since DVD discs are recorded in various image formats, they will look different depending on the software, the type of TV, and the TV aspect ratio setting.

### BD Wise

**(Samsung products only)**

BD Wise is Samsung's latest inter-connectivity feature. When you connect Samsung products with BD-Wise to each other via HDMI, the optimum resolution will be set automatically.

- **On** : The original resolution of the DVD disc will be output to the TV direct.
- **Off** : The output resolution will be fixed according to the Resolution previously set, regardless of the resolution of the disc.

✎ NOTE

- This will optimize the picture quality according to the content (In the disc, DVD, etc) that you want to play and the product or your BD Wise-compliant Samsung TV.
- If you want to change the resolution in BD Wise mode, you must set BD mode to Off in advance.
- BD Wise will be disabled if the product is connected to a device that does not support BD Wise.

### Resolution

Sets the output resolution of the HDMI video signal. The number in 480p(576p), 720p, 1080i and 1080p indicates the number of lines of video.
The i and p indicate interlace and progressive scan, respectively.

- **BD Wise** : Automatically sets the optimal resolution when connected via HDMI to a TV with the BD Wise feature. (The BD Wise menu item appears only if BD Wise is set to On.)
- **480p(576p)** : Outputs 480 lines of progressive video.
- **720p** : Outputs 720 lines of progressive video.
- **1080i** : Outputs 1080 lines of interlaced video.
- **1080p** : Outputs 1080 lines of progressive video.

✎ NOTE

- If Component or Composite is connected, the resolution supports only 480i(576i).
- 1080P may not appear depending on TV.

### HDMI Format

You can optimize the colour setting from the HDMI output. Select a connected device Type.

- **TV :** Select if connected to a TV via HDMI.
- **Monitor :** Select if connected to a Monitor via HDMI.

Audio

# Speaker Setting

## Speaker Size

You can set the Speaker Size of the Centre, Rear Speakers and also Test Tone in this mode.




- For the Front speakers, the mode is set to Small.
- For the Subwoofer, the mode is set to Present.
- For the Centre and Rear speakers, you can switch the mode to Small or None.
  - **Small** : Select this when using the speakers.
  - **None** : Select this when no speaker is connected.

**NOTE**

- The speaker mode may vary depending on Dolby Pro Logic and Stereo settings.

## Sound Edit

You can adjust the balance and level for each speaker.




Press the ▲▼ buttons to select and adjust the desired speaker.
Press the ◄► buttons to adjust the settings.

### Adjusting Front/Rear Speaker Balance

- You can select between 0 and -6.
- The volume decreases as you move closer to –6.

### Adjusting Centre/Rear/Subwoofer Speaker Level

- The volume level can be adjusted in steps from +6dB to –6dB.
- The sound gets louder as you move closer to +6dB and quieter as you get closer to -6dB.

## Delay Time

If the speakers cannot be placed at equal distances from the listening position, you can adjust the delay time of the audio signals from the Centre and Rear speakers. You can also set Test Tone in this mode.

### Setting up the Speaker Delay Time

When 5.1CH Surround Sound is played, you can enjoy the best sound if the distance between you and each speaker is the same.
Since the sounds arrive at the listening position at different times depending on the placement of speakers, you can adjust this difference by adding a delay effect to the sound of the Centre and Rear Speakers.




**NOTE**

- The Delay Time menu will be activated only when a 5.1 channel source is played.
- You can not set Centre and Rear in this mode when Centre or Rear of Speaker Size is set to None.




It is desirable to place all speakers within this circle.

Df: The distance from Front Speaker
Dc: The distance from Centre Speaker
Dr: The distance from Rear Speaker

### Setting the Centre Speaker

If the distance of Dc is equal to or longer than the distance of Df in the figure, set the mode as 0ms. Otherwise, change the setting according to the table.

| Distance between Df and Dc | 0.00m | 0.34m | 0.68m | 1.06m | 1.40m | 1.76m |
|---|---|---|---|---|---|---|
| Delay Time | 00 ms | 01 ms | 02 ms | 03 ms | 04 ms | 05 ms |

### Setting the Rear Speaker

If the distance of Dc is equal to or longer than the distance of Dr in the figure, set the mode as 0ms. Otherwise, change the setting according to the table.

| Distance between Dr and Dc | 0.00m | 1.06m | 2.11m | 3.16m | 3.62m | 5.29m |
|---|---|---|---|---|---|---|
| Delay Time | 00 ms | 03 ms | 06 ms | 09 ms | 12 ms | 15 ms |

**NOTE**

- With PL II (Dolby Pro Logic II), the delay time may be different for each mode.
- With AC-3 and DTS, the delay time can be set between 00 and 15mSEC.
- The Centre channel is only adjustable on 5.1 channel discs.

### Test Tone

Use the Test Tone feature to check the speaker connections.

- Press the ◄► buttons to select **On**.
- The test tone will be sent to **Front Left → Center → Front Right → Rear Right → Rear Left → Subwoofer** in order.
  To stop the test tone, press the **ENTER** button.

## ASC (Auto Sound Calibration) Setting

By setting the Auto Sound Calibration(ASC) function just once when you relocate or install the product, you can have the product automatically recognize the distance between speakers, levels between channels, and frequency characteristics to create a 5.1-channel sound field optimized for your environment.




L: Front Speaker (L)
R: Front Speaker (R)
C: Centre Speaker
SW: Subwoofer
SL: Rear Speaker (L)
SR: Rear Speaker (R)

✎ NOTE

- ASC setup can be made when there is no disc in the product.
- You cannot adjust the volume using the volume control buttons, because the volume level is fixed during the ASC setup.
- If the auto sound microphone is disconnected during the ASC setup, the setup will be cancelled.
- When ASC function is activated, the DSP/EQ, Dolby Pro Logic II and P. BASS sound effects will not work.
- If the product is connected to external devices or other components (such as an AUX, D.IN), the ASC Setup may not work exactly.

### Auto Sound Calibration

You will hear either the **ASC** mode or the User Speaker Settings.

- **On:** You will hear sound in the Auto Sound Calibration(ASC) mode.
- **Off:** You will hear sound in the Speaker Setting value.




### Auto Sound Calibration Setting

1. Plug the ASC microphone into the ASC input jack.
2. Place the ASC microphone at the listening position.

- Auto Sound Calibration will be automatically set up in the following sequence:
  Front Left ➞ Center ➞ Front Right ➞ Rear Right ➞ Rear Left ➞ Subwoofer
- Press the **RETURN** button to cancel the Auto Sound Calibration Setting.
- When the message "**REMOVE MIC**" appears on the display, unplug the ASC microphone.

✎ NOTE

- Setting the **Auto Sound Calibration** function takes about 3 minutes.

## DRC (Dynamic Range Compression)

This feature balances the range between the loudest and quietest sounds. You can use this function to enjoy Dolby Digital sound when watching movies at low volume at night.

- You can select either off, 2/8, 4/8, 6/8, Full.

## AV-SYNC

Video and audio sync may not match with digital TV. If this occurs, adjust the audio delay time to match the video

- You can set the audio delay time between 0 msec and 300 msec. Set it to the optimal status.

## HDMI AUDIO

The audio signals transmitted over the HDMI Cable can be toggled On/Off.

- **On :** Both video and audio signals are transmitted over the HDMI connection cable, and audio is output through your TV speakers only.
- **Off :** Video is transmitted over the HDMI connection cable only, and audio is output through the product speakers only.

✎ NOTE

- The default setting of this function is HDMI Audio Off.
- HDMI Audio is automatically down-mixed to 2ch for TV speakers.
- When HDMI Audio is set to On, PL II /DSP EQ /P.BASS doesn't work.
- In the iPod mode, this menu is not available.

## EQ Optimizer

Set optimal EQ automatically depending on the region.

- **Off:** Turn EQ Optimizer off.
- **On:** Turn EQ Optimizer on.

## System

### Initial Setting

By using the Initial Setting, you can set language, TV aspect and ASC(Auto Sound Calibration) setting.

Check if the ASC microphone is connected to the product.

✎ **NOTE**

- If an HDMI cable is connected to the product, the TV aspect does not appear and it is set to 16:9 Wide automatically.

### DivX(R) Registration

View DivX(R) VOD Registration Code to purchase and play DivX(R) VOD content.

## Language

You can select the language you prefer for on-screen menu, disc menu, etc.

| | |
|---|---|
| OSD Language | Select the language for the on-screen displays. |
| Disc Menu | Select the language for the disc menu displays. |
| Audio | Select the language for disc audio. |
| Subtitle | Select the language for disc subtitles. |

※ To select another language, select Others of Disc Menu, Audio and Subtitle, and enter the country code. (see page 43).

※ You cannot select Others in the OSD Language menu.

✎ **NOTE**

- The selected language will only appear if it is supported on the disc.

## Security

The Parental Lock function works in conjunction with DVDs that have been assigned a rating which helps you control the types of DVDs that your family watches. There are up to 8 rating levels on a disc.

### Parental Rating

Select the rating level you want to set.
A larger number indicates that the program is intended for adult use only. For example, if you select up to Level 6, discs that contain Level 7, 8 will not play.

Enter the password and then press the **ENTER** button.

- The password is set to "7890" by default.
- Once the setup is complete, you will be taken to the previous screen.

### Change Password

Select **Change** and enter the 4-digit password to set the parental lock using the number buttons on the remote control.




#### If you forgot your password

1. Remove the disc.
2. Press and hold the **STOP** (■) button on the remote control for 5 seconds or more with no disc inside. All settings will revert to the factory settings.

## Support

### Product Information

Product information such as Model code, Software Version, etc. is provided.

# Basic Functions

## Disc Playback

Load a disc into the disc slot with the disc's label facing up.

**NOTE**

- Resume function: When you stop disc play, the product remembers where you stopped, so when you press **PLAY** button again, it will pick up where you left off. (This function works only with DVDs.)
  Press the **STOP** button twice during playback to disable the Resume function.
- If no buttons are pressed on the product or remote control for more than 3 minutes when the product is in Pause mode, it will be changed STOP mode.
- The initial screen may appear different, depending on the content of the disc.
- Pirated discs will not run in this product because it violates the CSS (Content Scrambling System : a copy protection system) recommendations.

※ ⊘ will appear when an invalid button is pressed.

## TV Screen Saver/Power Saving Function

- If the product is left in the stop mode more than 5 minutes without any user interface, a screen saver will appear on your TV.
- If the product is left in the screen saver mode for more than 20 minutes, the power will automatically turn off.

## Audio CD(CD-DA)/MP3/WMA Playback




1. Insert an Audio CD(CD-DA) or an MP3 Disc into the disc slot.
   - For an Audio CD, the first track will be played automatically.
     - Press the ⏮⏭ buttons to move to the previous/next track.
   - For the MP3/WMA disc, press the ◄► buttons to select **Music**, then press the **ENTER** button.
     - Press the ▲▼◄► buttons to select a desired file and press the **ENTER** button.
     - Press the ◄◄ ►► buttons to move to the previous/next pages.
2. Press the **STOP** (■) button to stop playback.

**NOTE**

- Some MP3/WMA-CDs may not play, depending on the recording mode.
- Table of contents of a MP3-CD varies depending on the MP3/WMA track format recorded on the disc.
- WMA-DRM files cannot be played.

## JPEG File Playback

Images captured with a digital camera or camcorder, or JPEG files on a PC can be stored on a CD and then played back with this product.

1. Insert a JPEG disc on the disc slot.
2. Press the ◄► buttons to select **Photo**, and then press the **ENTER** button.
3. Press the ▲▼ buttons to select the folder you want to play, and then press the **ENTER** button.
4. Press the ▲▼ buttons to select the photo you want to play, and then press the **ENTER** button.
   - The selected file will play and slide show will start.
   - To stop slide show, press the **PAUSE** (**II**) button.
   - You can view the previous/next file by pressing the ◄,► buttons during the slideshow mode.




## Rotate Function

JPEG

Press the **GREEN(B)** or **YELLOW(C)** button during the PAUSE mode.

- **GREEN(B)** Button: Rotate 90° Counterclock wise.
- **YELLOW(C)** Button: Rotate 90° Clockwise.

**NOTE**

- The maximum resolutions supported by this product are 5120 x 3480 (or 19.0 MPixel) for standard JPEG files and 2048 x 1536 (or 3.0 MPixel) for progressive image files.

## Using the Playback Function

### Forward/Reverse Search

DVD CD DivX MP3

Press the ◄◄ ►► buttons for Search Function.

◄◄ 1 → ◄◄ 2 → ◄◄ 3 → ◄◄ 4
►► 1 → ►► 2 → ►► 3 → ►► 4

**NOTE**

- During the fast playback of the CD, sound is only heard at 1 and 2 step speed.
- No sound is played in search mode.

### Skipping Scenes/Songs

DVD CD MP3 DivX

Press the I◄◄ ►►I buttons.

- Each time the button is pressed during playback, the previous or next chapter, track or directory (file) will be played.
- You cannot skip chapters consecutively.

### Slow Motion Play

DVD DivX

Press the **PAUSE** (**II**) button and then ►► button for Slow Motion play.

| | |
|---|---|
| DVD | I►1 →I►2 →I►3 |
| DivX | I►1 →I►2 →I►3 |

**NOTE**

- No sound is heard during slow playback.
- Reverse slow playback does not work.

## Step Motion Play

DVD DivX

Press the **PAUSE** button repeatly.

- The picture moves forward one frame each time the button is pressed during playback.

**NOTE**

- No sound is heard during step motion playback.

## 5 Minute Skip function

DivX

During playback, press the ◄,► button.

- Playback skips 5 minutes forward whenever you press the ► button.
- Playback skips 5 minutes backward whenever you press the ◄ button.

**NOTE**

- You can operate this function only on the DivX.

## Using the Disc Menu

DVD

You can view the menus for the audio language, subtitle language, profile, etc.

1. During playback, press the **DISC MENU** button on the remote control.
2. Press the ▲▼◄► buttons to make the desired selection, then press the **ENTER** button.

**NOTE**

- Depending on the disc, menu setup items may vary and this menu may not be available.

## Using the Title Menu

DVD

For DVDs containing multiple titles, you can view the title of each movie.

1. During playback, press the **TITLE MENU** button on the remote control.
2. Press the ▲▼◄► buttons to make the desired selection, then press the **ENTER** button.

**NOTE**

- Depending on the disc, menu setup items may vary and this menu may not be available.

## Repeat Playback

DVD CD MP3 DivX

### DVD/DivX Repeat

You can repeat the title, chapter or the section(A-B Repeat) of the DVD/DivX.

1. During the DVD/DivX playback, press the **REPEAT** button on the remote control.
2. Press the ▲▼ buttons to select a desired repeat mode, then press the **ENTER** button.
3. Press the ▲▼ buttons to select **Off** to return to normal play, then press the **ENTER** button.

| | |
|---|---|
| DVD-VIDEO | Title → Chapter → A - → Off |
| DivX | Track → Dir (Directory) → Disc → Off |

### CD/MP3 Repeat

1. During the CD/ MP3 playback, press the **REPEAT** button repeatedly to select the repeat mode you want.

| | |
|---|---|
| CD | → → ALL → → A-B<br>(Normal → Repeat Track → Repeat All → Random → Repeat Section A-B) |
| MP3 | → → → ALL → →<br>(Normal → Repeat Track → Repeat Dir (Directory) → Repeat All → Random) |

## A-B Repeat Playback

DVD CD

You can repeatedly play back a designated section of a DVD or CD.

1. During the DVD disc or CD playback, press the **REPEAT** button on the remote control.
2. For DVD, press the ▲▼ buttons to select **A-**. For CD press the **REPEAT** button repeatedly until A-B appears.
3. Press the **ENTER** button at the point where you want repeat play to start (A).
4. Press the **ENTER** button at the point where you want repeat play to stop (B).
5. To return to normal playback, For DVD, press the ▲▼ buttons to select to Off. For CD, press the **REPEAT** button to select to →.

✎ **NOTE**

- The A-B Repeat function does not operate with DivX, MP3 or JPEG discs.

## Displaying Disc Information



1. During the playback, press the **TOOLS** button on the remote control.
2. Press the ▲▼ buttons to select the desired item.
3. Press the ◄► buttons to make the desired setup change and then press the **ENTER** button.
   - You may use the number buttons of the remote control to control some item.
4. To make Disc information disappear, press the **TOOLS** button again.

**NOTE**

- If you are playing contents from the tools menu, some functions may not be enabled depending on the disc.
- You can also select DTS, Dolby Digital or Pro Logic, depending on the disc.
- Some tools menu may differ depending on discs and files.

### TOOLS menu

- **Title**( ) : To access the desired title when there is more than one in the disc. For example, if there is more than one movie on a DVD, each movie will be identified as a Title.
- **Chapter**( ) : Most DVD discs are recorded in chapters so that you can quickly find a specific chapter.
- **Playing time**( ) : Allows playback of the film from a desired time. You must enter the starting time as a reference. The time search function does not operate on some discs.
- **Audio**( ): Refers to the film's soundtrack language. A DVD Disc can contain up to 8 audio languages.
- **Subtitle**( ): Refers to the subtitle languages available in the disc. You will be able to choose the subtitle languages or, if you prefer, turn them off from the screen. A DVD Disc can contain up to 32 subtitle languages.
- **Angle**( ): When a DVD contains multiple angles of a particular scene, you can use the Angle function.

## Selecting the Audio Language

1. Press the **TOOLS** button.
2. Press the ▲▼ buttons to select **AUDIO** ( ) display.
3. Press the ◄► buttons or numeric buttons to select the desired audio language.
   - Depending on the number of languages on a DVD disc, a different audio language is selected each time the button is pressed.

## Selecting the Subtitle Language

DVD DivX

1. Press the **TOOLS** button.
2. Press the ▲▼ buttons to select **SUBTITLE** ( ) display.
3. Press the ◄► buttons or numeric buttons to select the desired subtitle language.
   - Depending on the number of languages on a DVD disc, a different subtitle language is selected each time the button is pressed.

**NOTE**

- Depending on the disc, the Subtitle and Audio Language functions may not be available.
- On the DivX file format, the subtitle languages may be represented by only numbers.

### Caption Function

DivX

- You must have some experience with video extraction and editing in order to use this feature properly.
- To use the caption function, save the caption file (*.smi) in the same file name as that of the DivX media file (*.avi) within the same folder.
  Example. Root Samsung_007CD1.avi
  Samsung_007CD1.smi
- Up to 60 alphanumeric characters or 30 East Asian characters (2 byte characters such as Korean and Chinese) for the file name.
- The subtitle of DivX files are *.smi, *.sub, *.srt over 148 kbyte is not supported.

## Angle Function

DVD

This function allows you to view the same scene in different angles.

1. Press the **TOOLS** button.
2. Press the ▲▼ buttons to select ANGLE ( ) display.
3. Press the ◄► buttons or numeric buttons to select the desired angle.

**NOTE**

- The Angle function works only with discs on which multiple angles have been recorded.

**Sound Mode**

## P.BASS

The P.BASS function provides a bass boost to reinforce the low frequencies.

The MP3 ENHANCE function provides better sound quality by upscaling the sampling frequency.

Press the **P.BASS** button.

| | |
|---|---|
| 2 Channel LPCM source | POWER BASS ON → POWER BASS OFF |
| MP3 file | POWER BASS ON → POWER BASS OFF → MP3 ENHANCE ON |

**NOTE**

- The P.BASS function is only available with 2 channel LPCM sources such as MP3, Divx, CD and WMA.
- The P.BASS function does not work with DSP/EQ or Dolby Pro Logic II modes.
  If you press P.BASS in the DSP/EQ mode, the DSP/EQ mode is automatically shut off and the P. BASS function will be turned on.
- The MP3 Enhancement function is only available with MP3 files.

## DSP (Digital Signal Processor)/EQ

- DSP (Digital Signal Processor) : DSP modes have been designed to simulate different acoustic environments.
- EQ : You can select ROCK, POP, or CLASSIC etc. to optimize the sound for the genre of music you are playing.

Press the **DSP/EQ** button.

| | |
|---|---|
| POPS, JAZZ, ROCK | Depending on the genre of music, you can select POP, JAZZ, and ROCK. |
| STUDIO | Provides a sense of presence as if in a studio. |
| CLUB | Simulates the sound of a dance club with a throbbing bass beat. |
| HALL | Provides a clear vocal as if listening in a concert hall. |
| MOVIE | Provides the feeling of a movie cinema. |
| CHURCH | Gives the feel of being in a grand church. |
| PASS | Select this for normal listening. |

## S.VOL (SMART VOLUME)

This will regulate and stabilize the volume level against a drastic volume change when changing channels or during a scene transition.

Press the **S.VOL** button.




- Each time the button is pressed, the selection changes as follows :

SVOL ON ⇄ SVOL OFF

## Dolby Pro Logic II Mode

You can select the desired Dolby Pro Logic II audio mode.

Press the **PL II** button.

| | |
|---|---|
| MUSIC | When listening to music, you can experience sound effects as if you are listening to the actual performance. |
| CINEMA | Adds realism to the movie soundtrack. |
| PROLOG | You can listen to a 2CH sound source in 5.1CH surround sound with all speakers active.<br>- A specifi c speaker(s) may not be output depending on the input signal |
| MATRIX | You will hear multi channel surround sound. |
| STEREO | Select this to listen to sound from the front left and right speakers and the subwoofer only. |

**NOTE**

- When selecting Pro Logic II mode, connect your external device to the AUDIO INPUT jacks (L and R) on the product. If you connect to only one of the inputs (L or R), you cannot listen to surround sound.
- The Pro Logic II function is only available in Stereo mode.

## Listening to Radio

### Using buttons on the Remote Control

1. Press the **FUNCTION** button to select **FM.**
2. Tune in to the desired station.
   - **Automatic Tuning 1** : When the ⏮ ⏭ buttons is pressed, a preset broadcast station is selected.
   - **Automatic Tuning 2** : Press and hold the **TUNING/CH** (∧ ∨) button to automatically search for active broadcasting stations.
   - **Manual Tuning** : Press the **TUNING/CH** (∧ ∨) button to increase or decrease the frequency incrementally.

### Using buttons on the product

1. Press the **FUNCTION** ( FUNC. ● ) button to select **FM.**
2. Select a broadcast station.
   - **Automatic Tuning 1** : Press the **STOP** ( ■ ) button to select **PRESET** and then press the ⏮ ⏭ buttons to select the preset station.
   - **Automatic Tuning 2** : Press the **STOP** ( ■ ) button to select **MANUAL** and then press and hold the ⏮ ⏭ buttons to automatically search the band.
   - **Manual Tuning** : Press the **STOP** ( ■ ) button to select **MANUAL** and then press the ⏮ ⏭ buttons to tune in to a lower or higher frequency.

## Setting Mono/Stereo

Press the **MO/ST** button.

- Each time the button is pressed, the sound switches between **STEREO** and **MONO**.
- In a poor reception area, select **MONO** for a clear, interference-free broadcast.

## Presetting Stations

Example : Presetting FM 89.10 in the memory

1. Press the **FUNCTION** button to select **FM**.
2. Press the **TUNING/CH** (∧ ∨) button to select <89.10>.
3. Press the **TUNER MEMORY** button.
   - Number flashes on the display.




4. Press the ⏮ ⏭ buttons to select preset number.
   - You can select between 1 and 15 presets.
5. Press the **TUNER MEMORY** button again.
   - Press the **TUNER MEMORY** button before number disappears from the display.
   - Number disappears from the display and the station is stored in memory.
6. To preset another station, repeat steps 2 to 5.
   - To tune in to a preset station, press the ⏮ ⏭ buttons on the remote control to select a channel.

## Connecting Microphone

You can enjoy the feeling of a karaoke bar in the comfort of your home.

Watch the video and sing along the lyrics displayed on the TV screen against the accompaniment.

1. Connect the microphone to the MIC jack on the side of the product.
2. Press the **ECHO** button to adjust the echo level of the microphone.

3. Press the **MIC VOL** button to adjust the voice volume of the microphone.

## USB Function

### Playing Media Files using the USB Host Feature

You can enjoy media files such as pictures, movies and music saved on an MP3 player, USB memory stick or digital camera in high quality video with 5.1 channel sound by connecting the storage device to the USB port of the product.



1. Connect the USB device to the USB port on the side of the product.
2. Press the **FUNCTION** button to select USB.
   - **USB** appears on the display screen and then disappears.
3. Press the ◄► buttons to select **Videos**, **Music** or **Photo**.
   - Select a file to play.

#### Safe USB Removal

To prevent damage to the memory stored in the USB device, perform safe removal before disconnecting the USB cable.

- Press the **YELLOW(C)** button.
  - **REMOVE** will appear on the display.
- Remove the USB cable.

**NOTE**

- To listen to your music files with 5.1 channel sound, you must set the Dolby Pro Logic II mode to Matrix. (See page 37)
- Remove the USB cable from the USB port slowly. Otherwise, it may cause damage to the USB port.

## Using an iPod (Option)

* Some models do not support this function.
You can enjoy music, video files from an iPod through the product.



### Listening to Music

You can play music files stored in the iPod player by connecting it to the product.




1. Press the **FUNCTION** button to select iPod.
2. Connect the iPod dock connector to the iPod Jack on the side of the product.
3. Place the iPod in the dock.
   - Your iPod is automatically turned on.
   - “iPod” appears on the TV screen.
4. Press the ◄► buttons to select Music.
5. Select the music file to play.
   - You can use the remote control or product to control simple playback functions such as the **PLAY**, **PAUSE**, **STOP**, **I◄◄/ ►►I**, **◄◄/ ►►** and **REPEAT** buttons. See page 13.

✎ **NOTE**

- Adjust the volume to a moderate level before you connect your iPod and product.
- When the product is powered on and you connect an iPod, the product will charge your iPod's battery.
- "Made for iPod" means that an electronic accessory has been designed to connect specifically to iPod and has been certified by the developer to meet Apple performance standards.
- "Works with iPhone" means that an electronic accessory has been designed to connect specifically to iPhone and has been certified by the developer to meet Apple performance standards.
- Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards.
- In the iPod mode, the HDMI Audio setting does not work.

## iPod Music categories

File information including the artist name, album name, music title and genre will be displayed according to the ID3 Tag information on the appropriate music file.

| | |
|---|---|
| **Artist** | To play by artist. |
| **Songs** | To play in numeric or alphabetical order |
| **Playlist** | To play by Playlist. |
| **Album** | To play by album. |
| **Generic** | To play by genre. |
| **Composers** | To play by composer. |

✎ **NOTE**

- The category list may differ, depending on the iPod model.
- What is an ID3 Tag?
  This is what is attached to an MP3 to carry information relevant to the file such as the title, artist, album, year, genre and a comment field.

## Watching a Movie

You can play video files stored in the iPod player by connecting it to the product.

1. Press the **FUNCTION** button to select IPOD.
2. Connect the iPod dock connector to the iPod Jack on the side of the product.
3. In the iPod screen, move to **Settings > Videos**, then set the **TV Out** option and the TV signal.
4. Place the iPod in the Dock.
   • "iPod" appears on the TV screen.
5. Press the ◄► buttons to select **Videos.**
6. Select the video file to play.
   - You can use the remote control or product to control simple playback functions such as the **PLAY**, **PAUSE**, **STOP**, **I◄◄ /►►I** and **◄◄ /►►** buttons. (See page 13.)

### iPod models that can be used with this product

| | | |
|---|---|---|
| **iPod nano** 3rd generation (video) | **iPod** 5th generation (video) | **iPod nano** 4th generation (video) |
| **iPod touch** 1st generation | **iPod touch** 2nd generation | **iPhone 3G** |
| **iPod classic** | **iPhone** | |

✎ **NOTE**

- Connect the VIDEO OUT jack (Composite) on the product to your TV. If you select iPod video while connecting the HDMI cable, a pop-up message will appear on the TV screen meaning that you need to change the TV VIDEO input source to Composite. Select "Yes" and change the Video input source on your TV to the Composite mode to watch the iPod Video file.
  See your TV owner's manual for more information.
- iPod Video is only available in Composite Video output.
- If you want to watch iPod video via VIDEO output, set HDMI CEC to off.
- No other screen than the playback one will appear on the TV screen. Check other screens on the iPod player.
- If connected iPod does not support video playback, "Cannot play video files saved on this iPod" message appears when you select the Video menu.
- Compatibility depends on the software version of your iPod. Keep the iPod S/W version up to date.

## CD Ripping

Converts audio sound of the CDDA(Compact Disc Digital Audio) into a MP3 file format before sending to a USB storage device.

1. Connect the USB device to your product.
2. Insert the CDDA disc into the CD tray.
3. Press the **CD RIPPING** button.

   - To start ripping the current track, press the **CD RIPPING** button on the remote control while the system is playing a track or stopped temporarily.
   - To rip the entire CD, press and hold the **CD RIPPING** button on the remote control.
     -"FULL CD RIPPING" appears on the display and ripping starts.
4. Press the **STOP** (■) button to stop ripping.
   - When the CD ripping is done, a directory named "RIPPING" will be created in the USB device and the ripped file will be saved in a format of "SAM-XXXX".MP3".

**NOTE**

- Do not disconnect the USB connection or the power cable during the CD ripping. Otherwise, it may cause damage to the data. To stop CD ripping, press the **STOP** button and disconnect the USB device after the system stops playing the CD completely.
- If you disconnect the USB connection during the CD ripping, the system will turn off and you will not be able to delete the ripped file.
- If you connect the USB device to the system while it is playing a CD, the system stops temporarily and will play again.
- DTS-CDs cannot be ripped.
- If the ripping duration is less than 5 seconds, a ripping file may not be created.
- CD ripping works only if the USB device is formatted in the FAT file system. (The NTFS file system is not supported.)
  For a list of compliant devices, refer to the specification of the USB host.
- The ripping is performed at a normal speed of x3. The ripping time may be longer with some USB devices.
- While the system is ripping a CD, the audio sound will not be output.
- Do not put touch or move the system while it is ripping a CD.
- When HDMI AUDIO is set to On, the CD Ripping function is not supported.

# Other Information

## Troubleshooting

Refer to the chart below when this product does not function properly. If the problem you are experiencing is not listed below or if the instruction below does not help, turn off the product, disconnect the power cord, and contact the nearest authorized dealer or Samsung Electronics Service Centre.

| Symptom | Check/Remedy |
|---|---|
| **I cannot eject the disc.** | • Is the power cord plugged securely into the outlet?<br>• Turn off the power and then turn it back on. |
| **The iPod fails to connect.** | • Check the condition of the iPod connector and Dock.<br>• Keep the iPod S/W version up to date. |
| **Playback does not start.** | • Check the region number of the DVD.<br>DVD discs purchased from abroad may not be playable.<br>• CD-ROMs and DVD-ROMs cannot be played on this product.<br>• Make sure that the rating level is correct. |
| **Playback does not start immediately when the Play/Pause button is pressed.** | • Are you using a deformed disc or a disc with scratches on the surface?<br>• Wipe the disc clean. |
| **Sound is not produced.** | • No sound is heard during fast playback, slow playback, and step motion playback.<br>• Are the speakers connected properly? Is the speaker setup correctly customized?<br>• Is the disc severely damaged? |
| **Sound can be heard only from a few speakers and not all 6.** | • On certain DVD discs, sound is output from the front speakers only.<br>• Check if the speakers are connected properly.<br>• Adjust the volume.<br>• When listening to a CD, radio or TV, sound is output to the front speakers only. Select "PROLOG" by pressing PL II (Dolby Pro Logic II) on the remote control to use all six speakers. |
| **Dolby Digital 5.1 CH Surround Sound is not produced.** | • Is there "Dolby Digital 5.1 CH" mark on the disc? Dolby Digital 5.1 CH Surround Sound is produced only if the disc is recorded with 5.1 channel sound.<br>• Is the audio language correctly set to Dolby Digital 5.1-CH in the information display? |
| **The remote control does not work.** | • Is the remote control being operated within its operation range of angle and distance?<br>• Are the batteries drained?<br>• Have you selected the mode (DVD RECEIVER/TV) functions of the remote control (DVD RECEIVER/TV) correctly? |
| **• Disc is rotating but no picture is produced.**<br>**• Picture quality is poor and picture is shaking.** | • Is the TV power on?<br>• Are the video cables connected properly?<br>• Is the disc dirty or damaged?<br>• A poorly manufactured disc may not be playable. |
| **Audio language and subtitles do not work.** | • Audio language and subtitles will not work if the disc does not contain them. |
| **The Disc/Title menu screen does not appear even when the Disc/Title function is selected.** | • Are you using a disc that does not contain menus? |
| **Aspect ratio cannot be changed.** | • You can play 16:9 DVDs in 16:9 WIDE mode, 4:3 LETTER BOX mode, or 4:3 PAN SCAN mode, but 4:3 DVDs can be seen in 4:3 ratio only. Refer to the DVD disc jacket and then select the appropriate function. |

| Symptom | Check/Remedy |
|---|---|
| • The product is not working. (Example: The power goes out or the front panel key doesn't work or a strange noise is heard.)<br>• The product is not working normally. | • Press and hold the **STOP** (■) button on the remote control for longer than 5 seconds with no disc (reset function).<br><br>**Using the RESET function will erase all stored settings. Do not use this unless necessary.** |
| The rating level password has been forgotten. | • While "NO DISC" message appears on the display of the product, press and hold the remote control's **STOP** (■) button for longer than 5 seconds. "**INIT**" appears on the display and all settings will return to the default values. And then press the **POWER** button.<br>**Using the RESET function will erase all stored settings. Do not use this unless necessary.** |
| Can't receive radio broadcast. | • Is the antenna connected properly?<br>• If the antenna's input signal is weak, install an external antenna in an area with good reception. |

## Country code list

Enter the appropriate code number for Others of Disc Menu, Audio and Subtitle. (See page 30).

| Code | Language | Code | Language | Code | Language | Code | Language | Code | Language | Code | Language |
|---|---|---|---|---|---|---|---|---|---|---|---|
| 1027 | Afar | 1142 | Greek | 1239 | Interlingue | 1345 | Malagasy | 1482 | Kirundi | 1527 | Tajik |
| 1028 | Abkhazian | 1144 | English | 1245 | Inupiak | 1347 | Maori | 1483 | Romanian | 1528 | Thai |
| 1032 | Afrikaans | 1145 | Esperanto | 1248 | Indonesian | 1349 | Macedonian | 1489 | Russian | 1529 | Tigrinya |
| 1039 | Amharic | 1149 | Spanish | 1253 | Icelandic | 1350 | Malayalam | 1491 | Kinyarwanda | 1531 | Turkmen |
| 1044 | Arabic | 1150 | Estonian | 1254 | Italian | 1352 | Mongolian | 1495 | Sanskrit | 1532 | Tagalog |
| 1045 | Assamese | 1151 | Basque | 1257 | Hebrew | 1353 | Moldavian | 1498 | Sindhi | 1534 | Setswana |
| 1051 | Aymara | 1157 | Persian | 1261 | Japanese | 1356 | Marathi | 1501 | Sangro | 1535 | Tonga |
| 1052 | Azerbaijani | 1165 | Finnish | 1269 | Yiddish | 1357 | Malay | 1502 | Serbo-Croatian | 1538 | Turkish |
| 1053 | Bashkir | 1166 | Fiji | 1283 | Javanese | 1358 | Maltese | 1503 | Singhalese | 1539 | Tsonga |
| 1057 | Byelorussian | 1171 | Faeroese | 1287 | Georgian | 1363 | Burmese | 1505 | Slovak | 1540 | Tatar |
| 1059 | Bulgarian | 1174 | French | 1297 | Kazakh | 1365 | Nauru | 1506 | Slovenian | 1543 | Twi |
| 1060 | Bihari | 1181 | Frisian | 1298 | Greenlandic | 1369 | Nepali | 1507 | Samoan | 1557 | Ukrainian |
| 1069 | Bislama | 1183 | Irish | 1299 | Cambodian | 1376 | Dutch | 1508 | Shona | 1564 | Urdu |
| 1066 | Bengali; Bangla | 1186 | Scots Gaelic | 1300 | Canada | 1379 | Norwegian | 1509 | Somali | 1572 | Uzbek |
| 1067 | Tibetan | 1194 | Galician | 1301 | Korean | 1393 | Occitan | 1511 | Albanian | 1581 | Vietnamese |
| 1070 | Breton | 1196 | Guarani | 1305 | Kashmiri | 1403 | (Afan) Oromo | 1512 | Serbian | 1587 | Volapuk |
| 1079 | Catalan | 1203 | Gujarati | 1307 | Kurdish | 1408 | Oriya | 1513 | Siswati | 1613 | Wolof |
| 1093 | Corsican | 1209 | Hausa | 1311 | Kirghiz | 1417 | Punjabi | 1514 | Sesotho | 1632 | Xhosa |
| 1097 | Czech | 1217 | Hindi | 1313 | Latin | 1428 | Polish | 1515 | Sundanese | 1665 | Yoruba |
| 1103 | Welsh | 1226 | Croatian | 1326 | Lingala | 1435 | Pashto, Pushto | 1516 | Swedish | 1684 | Chinese |
| 1105 | Danish | 1229 | Hungarian | 1327 | Laothian | 1436 | Portuguese | 1517 | Swahili | 1697 | Zulu |
| 1109 | German | 1233 | Armenian | 1332 | Lithuanian | 1463 | Quechua | 1521 | Tamil | | |
| 1130 | Bhutani | 1235 | Interlingua | 1334 | Latvian, Lettish | 1481 | Rhaeto-Romance | 1525 | Tegulu | | |

# Other Information

## Specifications

| | | |
|---|---|---|
| General | Weight | 3.0 Kg |
| | Dimensions | 433 (W) x 142 (H) x 208 (D) mm |
| | Operating Temperature Range | +5°C~+35°C |
| | Operating Humidity Range | 10 % to 75 % |
| FM Tuner | Signal/noise ratio | 70 dB |
| | Usable sensitivity | 10 dB |
| | Total harmonic distortion | 0.5 % |
| Disc | DVD (Digital Versatile Disc) | Reading Speed : 3.49 ~ 4.06 m/sec. |
| | | Approx. Play Time (Single Sided, Single Layer Disc) : 135 min. |
| | CD : 12 cm (COMPACT DISC) | Reading Speed : 4.8 ~ 5.6 m/sec. |
| | | Maximum Play Time : 74 min. |
| | CD : 8cm (COMPACT DISC) | Reading Speed : 4.8 ~ 5.6 m/sec. |
| | | Maximum Play Time : 20 min. |
| Video Output | Composite Video | 480i(576i) |
| | | 1 channel : 1.0 Vp-p (75 Ω load) |
| | Component Video | 480i(576i) |
| | | Y : 1.0 Vp-p (75 Ω load) |
| | | Pr : 0.70 Vp-p (75 Ω load) |
| | | Pb : 0.70 Vp-p (75 Ω load) |
| Video/Audio | HDMI | 1080p, 1080i, 720p, 480p(576p) |
| Amplifier | Front speaker output | 133W x 2(3Ω) |
| | Centre speaker output | 133W(3Ω) |
| | Rear speaker output | 133W x 2(3Ω) |
| | Subwoofer output | 135W(3Ω) |
| | Frequency range | 20Hz~20KHz |
| | S/N Ratio | 70dB |
| | Channel separation | 60dB |
| | Input sensitivity | (AUX)400mV |

*: Nominal specification

- Samsung Electronics Co., Ltd reserves the right to change the specifications without notice.
- Weight and dimensions are approximate.
- Design and specifications are subject to change without prior notice.
- For the power supply and Power Consumption, refer to the label attached to the product.

## HT-C750W

| | | | | | |
|---|---|---|---|---|---|
| Speaker | Speaker system | 5.1ch speaker system | | | |
| | | Front | Rear | Centre | Subwoofer |
| | Impedance | 3 Ω | 3 Ω | 3 Ω | 3 Ω |
| | Frequency range | 140Hz~20KHz | 140Hz~20KHz | 140Hz~20KHz | 40Hz~160Hz |
| | Output sound pressure level | 86dB/W/M | 86dB/W/M | 86dB/W/M | 88dB/W/M |
| | Rated input | 133W | 133W | 133W | 135W |
| | Maximum input | 266W | 266W | 266W | 270W |
| | Dimensions (W x H x D) | Front : 90 x 334.5 x 68.5 mm (stand base:109 x 98)<br>Rear : 90 x 207.5 x 68.5 mm<br>Centre : 360 x 74.5 x 68.5 mm<br>Subwoofer : 168 x 350 x 295 mm | | | |
| | Weights | Front : 1.19 Kg, Rear : 0.67 Kg<br>Centre : 0.57 Kg, Subwoofer : 4.5 Kg | | | |

## HT-C755W

| | | | | | |
|---|---|---|---|---|---|
| Speaker | Speaker system | 5.1ch speaker system | | | |
| | | Front | Rear | Centre | Subwoofer |
| | Impedance | 3 Ω | 3 Ω | 3 Ω | 3 Ω |
| | Frequency range | 140Hz~20KHz | 140Hz~20KHz | 140Hz~20KHz | 40Hz~160Hz |
| | Output sound pressure level | 86dB/W/M | 86dB/W/M | 86dB/W/M | 88dB/W/M |
| | Rated input | 133W | 133W | 133W | 135W |
| | Maximum input | 266W | 266W | 266W | 270W |
| | Dimensions (W x H x D) | Front/Rear : 94 x 1300 x 90 mm (stand base: Ø308 mm)<br>Centre : 360 x 74.5 x 68.5 mm<br>Subwoofer : 168 x 350 x 295 mm | | | |
| | Weights | Front /Rear : 3.52 Kg<br>Centre : 0.57 Kg, Subwoofer : 4.5 Kg | | | |

## SWA-5000

| | |
|---|---|
| Power Consumption | 50 W |
| Weight | 1.1 kg |
| Dimensions (W x H x D) | 76.2mm x 228.6mm x 152.4mm |
| Operating Temperature Range | +5°C to +35°C |
| Operating Humidity Range | 10% ~ 75% |
| Output | 133W x 2 CH |
| Frequency range | 20Hz~20KHz |
| S/N Ratio | 65dB |

## Contact SAMSUNG WORLD WIDE

If you have any questions or comments relating to Samsung products, please contact the SAMSUNG customer care centre.

| Area | Contact Center ☎ | Web Site |
|---|---|---|
| **▪ North America** | | |
| Canada | 1-800-SAMSUNG (726-7864) | www.samsung.com |
| Mexico | 01-800-SAMSUNG (726-7864) | www.samsung.com |
| U.S.A | 1-800-SAMSUNG (726-7864) | www.samsung.com |
| **▪ Latin America** | | |
| Argentine | 0800-333-3733 | www.samsung.com |
| Brazil | 0800-124-421<br>4004-0000 | www.samsung.com |
| Chile | 800-SAMSUNG (726-7864) | www.samsung.com |
| Nicaragua | 00-1800-5077267 | www.samsung.com |
| Honduras | 800-7919267 | www.samsung.com |
| Costa Rica | 0-800-507-7267 | www.samsung.com |
| Ecuador | 1-800-10-7267 | www.samsung.com |
| El Salvador | 800-6225 | www.samsung.com |
| Guatemala | 1-800-299-0013 | www.samsung.com |
| Jamaica | 1-800-234-7267 | www.samsung.com |
| Panama | 800-7267 | www.samsung.com |
| Puerto Rico | 1-800-682-3180 | www.samsung.com |
| Rep. Dominica | 1-800-751-2676 | www.samsung.com |
| Trinidad & Tobago | 1-800-SAMSUNG (726-7864) | www.samsung.com |
| Venezuela | 0-800-100-5303 | www.samsung.com |
| Colombia | 01-8000112112 | www.samsung.com |
| **▪ Europe** | | |
| Austria | 0810 - SAMSUNG<br>(7267864, € 0.07/min) | www.samsung.com |
| Belgium | 02-201-24-18 | www.samsung.com/<br>be (Dutch)<br>www.samsung.com/<br>be_fr (French) |
| Czech | 800 - SAMSUNG<br>(800-726786) | www.samsung.com |
| Denmark | 70 70 19 70 | www.samsung.com |
| Finland | 030 - 6227 515 | www.samsung.com |
| France | 01 48 63 00 00 | www.samsung.com |
| Germany | 01805 - SAMSUNG<br>(726-7864 € 0,14/Min) | www.samsung.com |
| Hungary | 06-80-SAMSUNG (726-7864) | www.samsung.com |
| Italia | 800-SAMSUNG (726-7864) | www.samsung.com |
| Luxemburg | 261 03 710 | www.samsung.com |
| Netherlands | 0900-SAMSUNG<br>(0900-7267864) (€ 0,10/Min) | www.samsung.com |
| Norway | 815-56 480 | www.samsung.com |
| Poland | 0 801 1SAMSUNG (172678)<br>022-607-93-33 | www.samsung.com |
| Portugal | 80820-SAMSUNG (726-7864) | www.samsung.com |
| Slovakia | 0800-SAMSUNG (726-7864) | www.samsung.com |
| Spain | 902 - 1 - SAMSUNG<br>(902 172 678) | www.samsung.com |
| Sweden | 0771 726 7864 (SAMSUNG) | www.samsung.com |
| U.K | 0845 SAMSUNG (7267864) | www.samsung.com |
| Eire | 0818 717100 | www.samsung.com |

| Area | Contact Center ☎ | Web Site |
|---|---|---|
| Switzerland | 0848 - SAMSUNG (7267864,<br>CHF 0.08/min) | www.samsung.com/ch<br>www.samsung.com/<br>ch_fr/ (French) |
| Lithuania | 8-800-77777 | www.samsung.com |
| Latvia | 8000-7267 | www.samsung.com |
| Estonia | 800-7267 | www.samsung.com |
| **▪ CIS** | | |
| Russia | 8-800-555-55-55 | www.samsung.com |
| Georgia | 8-800-555-555 | |
| Armenia | 0-800-05-555 | |
| Azerbaijan | 088-55-55-555 | |
| Kazakhstan | 8-10-800-500-55-500 | |
| Uzbekistan | 8-10-800-500-55-500 | www.samsung.com |
| Kyrgyzstan | 00-800-500-55-500 | www.samsung.com |
| Tadjikistan | 8-10-800-500-55-500 | www.samsung.com |
| Ukraine | 0-800-502-000 | www.samsung.ua<br>www.samsung.com/<br>ua_ru |
| Belarus | 810-800-500-55-500 | |
| Moldova | 00-800-500-55-500 | |
| **▪ Asia Pacific** | | |
| Australia | 1300 362 603 | www.samsung.com |
| New Zealand | 0800 SAMSUNG (0800 726 786) | www.samsung.com |
| China | 400-810-5858<br>010-6475 1880 | www.samsung.com |
| Hong Kong | (852) 3698-4698 | www.samsung.com/<br>hk<br>www.samsung.com/<br>hk_en/ |
| India | 3030 8282<br>1800 110011<br>1800 3000 8282<br>1800 266 8282 | www.samsung.com |
| Indonesia | 0800-112-8888<br>021-5699-7777 | www.samsung.com |
| Japan | 0120-327-527 | www.samsung.com |
| Malaysia | 1800-88-9999 | www.samsung.com |
| Philippines | 1-800-10-SAMSUNG<br>(726-7864)<br>1-800-3-SAMSUNG<br>(726-7864)<br>1-800-8-SAMSUNG<br>(726-7864)<br>02-5805777 | www.samsung.com |
| Singapore | 1800-SAMSUNG (726-7864) | www.samsung.com |
| Thailand | 1800-29-3232<br>02-689-3232 | www.samsung.com |
| Taiwan | 0800-329-999 | www.samsung.com |
| Vietnam | 1 800 588 889 | www.samsung.com |
| **▪ Middle East & Africa** | | |
| Turkey | 444 77 11 | www.samsung.com |
| South Africa | 0860-SAMSUNG (726-7864) | www.samsung.com |
| U.A.E | 800-SAMSUNG (726-7864) | www.samsung.com |
| Bahrain | 8000-4726 | |
| Jordan | 800-22273 | |

SAMSUNG